Name:	Date: Odemeter:	: Hours:	VEH04 Inspection	
SERVICE TYPE: Training_	Emergency Response_	Standby	Maintenance	

## POLARIS UTVs (5534, 5536)

## **CHECK AFTER EACH APPARATUS USE**

	Required Status	ОК	Exception Status
Fuel Level	Minimum ¾ Full (Gasoline)		
Headlights	Turned OFF		
Chassis Lights	All operational		
Emergency Lights	All operational		
2wd/4wd/6wd	Set to 2wd		
Parking Brake	ON		
Transmission	Set to NEUTRAL		
Radio	Response Mode BCFD-S, Default scan ON,		
	Volume level SET to inside level		
Ignition Switch	OFF		
Shore Power	Connected, confirm power ON		
Spot thermometer	In Glovebox		
Map Book	Present, all Topos & reference cards in place		
Tires	Visually inspect, thump to check pressure		
SCBA Tanks	OFF –Full		
H20/Air Valves	OFF		
Water Tank Level	Full with foam added		
Wildland Hand Tools	Confirm in bed		
Chainsaw and tools	Present - chainsaw manager will maintain		
Seat and steering wheel	Wipe down if your hand would come away dirty		
clean			

## POLARIS UTVs (5534, 5536)

## IN ADDITION COMPLETE MONTHLY OR AFTER MAJOR INCIDENT

	Required Status	ОК	Exception Status
Engine Oil Level	15-30 Multi-Purpose oil (dipstick located under		
	seat)		
Radiator Fluid Level	Full to mark		
Batteries	Terminals clean and tight (battery located under		
	seat)		
Belts	Clean, tight & in good condition (located under		
	seat on Driver's side; remove plastic cover)		
Air Filter	Visually check, blow out dirt (located under bed)		
Tires	Visually inspect for damage & verify pressure at 10psi		
Winch –front and rear	Operational - Extension & retraction – leave in		
Willen – Hont and real	Free-Wheel Mode (knob on end on driver's side).		
	Verify that tree strap or chain is present in cargo		
	box.		
Drinking H20	Present in Cargo box		
Drive for at least 3 minutes	Verify steering and suspension feels tight.		
brive for at least 5 minutes	Verify that brakes seem adequate, no grabbing or		
	noise.		
	Verify parking brake will hold on moderate+ hill.		
	Verify belt not slipping and that clutch is not		
	excessively grabby. Replace belt if necessary.		
	Order a new spare or report up. Verify new spare		
	is in place within 7 days.		
Seat, steering wheel, floor,	Wipe down and wash with soapy water if your		
body, controls, and tools all	hand would come away dirty.		
clean			
5534 Only			
Water Tank Level	Spray foam to keep foam from congealing. Refill		
	water, add foam. If insufficient water flow, use		
	winch to pick up water unit, clean filter on bottom		
	of passenger side.		
Control Panel valves	Confirm operational, (attach hose and test water		
	& air pressures.		
Hoses and nozzles	Secured in cargo bed		
Water Packs (2)	Full & ready for use		
Wildland tools	Clean, sharpened, tape over cutting edges		
5536 Only			
Inspect med person seat	Seatbelt tidy, seat clean		
Inspect med compartment	Neatly organized and stocked		